

Covers for Fire Alarm Devices



Surface-mount models include a conduit spacer and are designed to cover devices mounted to an electrical gang box.

Indoor/Outdoor Pull Station Covers—Deter malicious and accidental fire alarms without restricting legitimate alarms. Covers with alarms have a 95/105dB selectable horn that activates when cover is opened.

Horn/Strobe Covers—Help protect strobes and horn/strobes from damage and vandalism. Horn/Strobe Covers have sound openings.



1DPD7



2KFK3



2KFK7




1DPE2

	FLUSH MOUNT					SURFACE MOUNT				
Description	H	W	D	Mfr. Model	Item No.	H	W	D	Mfr. Model	Item No.
Indoor Pull Station Covers										
With Alarm	8 7⁄8 in	6 1⁄8 in	3 1⁄4 in	STI-1100	1DPD7	8 7⁄8 in	6 1⁄8 in	5 1⁄4 in	STI-1130	2KFK3
Without Alarm	8 7⁄8 in	5 3⁄8 in	4 in	STI-13020FR	34D123	5 1⁄2 in	4 1⁄8 in	3 3⁄8 in	STI-13220FR	45YP78
Without Alarm	8 7⁄8 in	6 1⁄8 in	3 1⁄4 in	STI-1200	1DPD6	8 7⁄8 in	6 1⁄8 in	5 1⁄4 in	STI-1230	2KFK4
Indoor/Outdoor Pull Station Covers										
With Alarm	8 7⁄8 in	5 1⁄2 in	2 3⁄4 in	STI-13020NR	5AFY1	8 7⁄8 in	5 1⁄2 in	4 in	STI-13220NR	5AFY2
Without Alarm	8 7⁄8 in	5 1⁄2 in	2 3⁄4 in	STI-13000NC	5AFX7	8 7⁄8 in	5 1⁄2 in	4 in	STI-13200NC	5AFY4
Without Alarm, Fire Label	8 7⁄8 in	5 1⁄2 in	2 3⁄4 in	STI-13010FR	5AFX8	8 7⁄8 in	5 1⁄2 in	4 in	STI-13210FR	5AFX9
Without Alarm	8 7⁄8 in	6 1⁄8 in	3 1⁄4 in	STI-1250	2KFK7	10 1⁄4 in	7 1⁄4 in	5 1⁄2 in	STI-3150	2KFK5
Horn/Strobe Covers										
Polycarbonate	8 1⁄2 in	6 1⁄2 in	4 in	STI-1210E	1DPE2	8 1⁄2 in	6 1⁄2 in	5 3⁄4 in	STI-1210D	1DPD9
Description										Item No.
Accessory for Pull Station Covers										
2 in Conduit Spacer										1DPD8



8C245



8C246



803EF6



Wire Covers

Help protect fire bells, clocks, beacons, and other devices from damage and vandalism. 3FVP5 is compatible with low-profile and flush-mount units.

Color	H	W	D	Item No.
Rectangle Covers				
White	10 1/2 in	13 3/4 in	2 3/4 in	8C245
White	10 3/4 in	26 3/4 in	11 1/4 in	8C246
White	7 3/4 in	6 in	6 in	9EK8
White	7 in	5 1/4 in	4 1/2 in	3FVP5
White	7 1/2 in	6 1/8 in	3 3/8 in	16D841
White	7 1/2 in	6 3/4 in	6 1/8 in	16D843
Red	7 1/2 in	6 3/4 in	6 1/8 in	16D844
Octagonal Covers				
White	20 3/4 in	20 3/4 in	3 3/8 in	803EF6



1DPE1

1DPF3



Audible Entry and Exit Alarms

ALARMS

Exit Stopper—In Exit Alarm mode, alarm can be set to sound for 30 sec., 3 min., or indefinitely. In Annunciator mode, detector announces door entry. Select 15-sec. entry delay or immediate alarm. Warning horn can be set to 95 or 105dB.

Wireless Alarm Kit—REX PLUS Electronic Watchdog detects movement in a selected indoor location. Features 4 selectable sounds: continuous rain forest, barking sound of an attack dog, rain forest sound to announce visitors, barking dog for 15 to 20 sec. then a continuous siren. Detects movement through walls, doors, and glass. Variable sensitivity (up to 30 ft.) plus a volume control. 110VAC.

ACCESSORIES

8-Channel Receiver 16D856 helps monitor up to 4 devices. Features a distinct beep and tone for each of the 4 devices. Latching memory LED (flashes until reset). Use with 16D849 Add-on Wireless Exit Stopper. 16D849 emits an ear piercing alarm when exit door is opened. Alarm announces door entry with a set of 10 beeps. Detects both unauthorized exits and entries.

Description	Color	Item No.
Exit Stopper		
Exit Stopper	Red	1DPE1
Exit Stopper, Double Door	Red	3JYV9
Exit Stopper with Remote Horn Alarm	Red	3JYW2
Wireless Alarm Kit		
REX PLUS Electronic Watchdog	Light Blue	1DPF3
Accessories		
8-Channel Receiver	White	16D856
Add-On Wireless Exit Stopper	Red	16D849



Wireless Entrance and Exit Announcers

Reduce surprise visits and missed deliveries with exit and entrance announcers.



38XL85



38XL86

Photoelectric Door Announcer—Activated when an individual passes between a photo beam and a reflector. Can be programmed to sound an alert or chime.

Combination PIR and Magnetic Contact Door and Entrance Alerts—Magnetic contacts activate chime/ alarm when door or window is opened. Wireless chimes are compatible, sold separately.

Description	Mfr. Model	Item No.
Photoelectric Door Announcer		
Doorbell Chime w/Receiver	STI-3350G	38XL84
Combination PIR/Magnetic Contact Entry Alert Chime		
Entry Alert Chime w/Receiver	STI-3360G	38XL85
Combination Passive Infrared (PIR) and Magnetic Contact Door and Entrance Alerts		
Motion-Activated Chime w/Recv	STI-3610G	38XL86
Doorbell Extender w/Receiver	STI-3300	38XL91
Chime Receiver	STI-3353	38XL87
Entry Alert Sensor	STI-3551	38XL88
Motion-Activated Sensor	STI-3601	38XL89
Doorbell Chime Sensor	STI-3301	38XL90



2EXU5



2EXV4

Magnetic Contacts

■ Vertical or horizontal mount; hardware included

Low-current magnetic contacts send a signal to an alarm or a supervised monitoring system when the door magnet moves away from the frame magnet. A gap between the contacts compensates for ill-fitting doors and windows opened for ventilation. Aluminum switches are sealed airtight to resist corrosion. 2EXV4 mounts directly to the track or channel of an overhead door.

Loop Configuration	Max. Gap Distance	Lead Size	L	W	H	Max. Voltage	Item No.
Surface-Mounted—Aluminum							
Open or Closed	1 1/4 in	#22 AWG	5/8 in	2 in	3/8 in	30V DC/V AC	2EXU5
Open or Closed	1 1/4 in	#22 AWG Armored Cable	5/8 in	2 in	3/8 in	30V DC/V AC	2EXU6
Surface-Mounted—Plastic							
Closed	1 1/4 in	#6 Screw	5/8 in	2 in	1/2 in	100V DC/V AC	2EXT7
Surface-Mounted for Overhead Doors—Aluminum							
Closed	2 3/4 in	#22 AWG Armored Cable	1 1/2 in	4 3/8 in	3/8 in	100V DC/V AC	2EXV4