

**1-800-GRAINGER (472-4643)**

**FLUKE.**

**DRANETZ**  
THE STANDARD FOR ENERGY & POWER MEASUREMENT

## Clamp-On Current Probes

Probes connect to compatible multimeters or testing equipment to extend their reach and measuring capabilities. Jaws clamp around conductors without disconnecting and interrupting the power supply. Extendable cables allow probes to connect with conductors in tight spaces and hard-to-reach locations.



**BNC Connector  
1W499**



**Shielded  
Coaxial Cable  
w/ BNC Plugs  
56GX96**



**Shrouded  
Banana Plugs  
4YE82**



**Shrouded  
Banana Plugs  
2HZC5**

Connector Type	Max. AC Current	Max. DC Current	Max. Conductor Size	Jaw Opening	Includes	Brand	Item No.	Pkg. Qty.
<b>CAT II 600V, CAT III 300V</b>								
BNC	110 A	110 A	0.46 in	0.5 in	—	Fluke	1W499	1
<b>CAT III 1000V, CAT IV 600V</b>								
Binder	40 A	—	0.63 in	0.6 in	Safety Sheet	Fluke	45LN82	3
	40 A	—	0.63 in	0.6 in	Safety Sheet	Fluke	45LN81	1
	400 A	—	1.25 in	1.2 in	Instructions	Fluke	4YE83	1
Dranetz TR Style	3,000 A	—	17 in	15 in	(2) AA Batteries, Instructions	Dranetz	4DZY3	1
	6,000 A	—	11 in	11.5 in	(2) AA Batteries, Instructions	Dranetz	4DZY5	1
Shielded Coaxial Cable with BNC Plugs	2,000 A	2,000 A	2.05 in	2 in	(3) AC/DC Current Clamps	Fluke	56GX96	1
	2,000 A	2,000 A	2.05 in	2 in	AC/DC Current Clamp	Fluke	56GX95	1
Shrouded Banana Plugs	400 A	400 A	1.25 in	1.2 in	Instructions	Fluke	4YE82	1
<b>CAT III 300V</b>								
Banana Plugs	20 A	30 A	0.75 in	0.7 in	Instructions	Fluke	2EWU9	1
BNC	20 A	30 A	0.75 in	0.7 in	Instructions	Fluke	2ATY3	1
	300 A	450 A	0.75 in	0.7 in	Instructions	Fluke	2EWU4	1
<b>CAT III 600V</b>								
BNC	200 A	—	0.79 in	0.8 in	BNC Input Connector	Fluke	4XL42	1
	3,000 A	—	2.52 in	2.5 in	Banana Adapter	Fluke	4PD23	1
	3,000 A	—	7 in	6.5 in	Instructions	Fluke	2EWU5	1
	3,000 A	—	7 in	10.5 in	Instructions	Fluke	2EWU6	1
Dranetz Hypertronics Connector	1.2 A	—	0.59 in	0.6 in	Instructions	Dranetz	4DZX2	1
	100 A	—	0.59 in	0.6 in	Instructions	Dranetz	4DZX1	1
Sheathed Banana Plugs	400 A	400 A	1.1 in	1.1 in	Case, Fluke-1410 Current Probe	Fluke	4CB81	1
	600 A	1,000 A	1.1 in	1.1 in	Case, Fluke-11010 Current Probe	Fluke	4CB82	1
Shrouded Banana Plugs	200 A	—	0.79 in	0.8 in	BNC Input Connector	Fluke	4XL41	1
	400 A	400 A	1.18 in	1.1 in	—	Fluke	4KF12	1
	600 A	1,000 A	1.18 in	1.1 in	9V Battery, Instructions	Fluke	4KF11	1
	800 A	—	2.13 in	2.1 in	Instructions	Fluke	2HZC5	1
<b>CAT III 600V, CAT IV 300V</b>								
BNC	1,000 A	—	2.13 in	2.1 in	Product Registration Card	Fluke	6MR11	1

**FLUKE.**

## Flexible Current Probes

Lightweight probes have flexible coil jaws that wrap or loop around conductors of different shapes and sizes, thick bundles of cables or wire, and circuit breaker panels or bus bars. Connect to compatible multimeters or other testing equipment to extend their reach and measurement capabilities in tight spaces and hard-to-reach locations.



**Binder  
45LN76**



**Fluke iFlex  
6FXH9**

Connector Type	Max. AC Current	Max. Conductor Size	Jaw Opening	Includes	Item No.	Pkg. Qty.
CAT III 1000V, CAT IV 600V						
Binder	1,500 A	4 in	12 in	Safety Sheet	45LN75	1
		4 in	12 in	Safety Sheet	45LN78	3
		4 in	12 in	Safety Sheet	45LN84	4
	3,000 A	8 in	24 in	Safety Sheet	45LN76	1
		8 in	24 in	Safety Sheet	45LN79	3
		8 in	24 in	Safety Sheet	45LN85	4
	6,000 A	12 in	36 in	Safety Sheet	45LN77	1
		12 in	36 in	Safety Sheet	45LN80	3
		12 in	36 in	Safety Sheet	45LN86	4
	Fluke iFlex	2.8 in	2.8 in	Instructions	6FXJ0	1
		5.7 in	5.7 in	Instructions	6FXH9	1
ODO	1,500 A	8 in	—	24 in Current Probes, Flexible Current Probe, Safety Sheet	444L88	1
		8 in	—	(3) 24 in Probes, Flexible Current Probe, Safety Sheet	444L89	1
		8 in	—	(4) 24 in Current Probes, Flexible Current Probe, Safety Sheet	444L90	1
	3,000 A	8 in	—	(4) 24 in Current Probes, Flexible Current Probe, Safety Sheet	444L93	1
		8 in	—	(3) 24 in Probes, Flexible Current Probe, Safety Sheet	444L92	1
		8 in	—	(4) 24 in Current Probes, Flexible Current Probe, Safety Sheet	444L91	1
	6,000 A	12 in	—	(4) 24 in Current Probes, Flexible Current Probe, Safety Sheet	444L96	1
		12 in	—	24 in Current Probes, Flexible Current Probe, Safety Sheet	444L94	1
		12 in	—	(3) 24 in Probes, Flexible Current Probe, Safety Sheet	444L95	1
		CAT III 600V				
BNC	3,000 A	24 in	24 in	(2) AA Batteries, Instructions	1DGX8	4
Safety Plugs	2,000 A	24 in	24 in	Banana Plug to BNC Adapter	1DGX7	1



**Safety Plugs  
1DGX7**

Sign in to **Grainger.com®** to see **YOUR Pricing** and **MORE**